



# PRECISION MOLDED FRONT FLOOR LINERS

(2021+ FORD BRONCO)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner

### TOOLS REQUIRED

---

N/A

SKU # FB12974



---

**STEP 1**



Remove any current floor mat/liner from the vehicle. Ensure the floor is clean of any dirt/debris.

---

**STEP 2**



Apply the front floor liner to the vehicle. Secure the circular cutouts in the liner with the mounts on the floor. Repeat this procedure for the remaining front floor liner.

Installation is now complete.