



PRECISION MOLDED FRONT AND REAR FLOOR LINERS

(2021+ FORD BRONCO - 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner
- (1) Rear Floor Liner

TOOLS REQUIRED

N/A

SKU # FB12975



**STEP 1
(FRONT)**



Remove any current floor mat/liner from the vehicle. Ensure the floor is clean of any dirt/debris.

**STEP 2
(FRONT)**



Apply the front floor liner to the vehicle. Secure the circular cutouts in the liner with the mounts on the floor. Repeat this procedure for the remaining front floor liner.



**STEP 3
(REAR)**



Remove any current floor mat/liner from the vehicle. Ensure the floor is clean of any dirt/debris.

**STEP 4
(REAR)**



Apply the rear floor liner to the vehicle. Align the rear section of the liner into place first, then manipulate the front portion under the front seats.

Installation is now complete.