



ALL WEATHER CARGO LINER

(2021+ BRONCO - 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Cargo Liner

TOOLS REQUIRED

Vacuum Cleaner
Heat Gun (Optional)

**STEP 1**

Clean the vehicle cargo area of any dirt/debris. Place the cargo liner into the cargo area, ensuring the sides and corners align with the plastic trim panels.

Note: If liner is deformed from shipping, use a light amount of heat to reform the liner.

**STEP 2**

Optional: Using a razor knife, cut the corners at the designated moldings to gain access to the floor tie-downs.

Installation is now complete.