



# ARM REST STORAGE TRAY SET

(2021+ BRONCO)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Upper Storage Tray  
(1) Lower Storage Tray

### TOOLS REQUIRED

---

N/A

**STEP 1**

Clean the center console of its contents. Place the lower storage tray into the center console. The tray will fit within the grooves in the center console.

**STEP 2**

Place the upper storage tray on top of the lower storage tray. Close the center console lid to confirm fitment.

Installation is now complete.