

## RUBBER ARM REST COVER

(2021+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

TOOLS REQUIRED

(1) Arm Rest Cover

Heat Gun (Optional)





STEP 1

Open the center console lid. Align the center console cover to the lid, and stretch the sides of the cover around towards the inside of the lid.

Note: Using a heat gun to heat the rubber may be necessary to ease stretching process.



STEP 2

Installation is now complete.