

FRONT DOOR HANDLE STORAGE COMPARTMENT

(2021+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Panel
- (1) RH Panel
- (1) Adhesion Promoter Pad

TOOLS REQUIRED

N/A





STEP 1

Under the interior door grab handle, clean the door panel using the include adhesion promoter pad. Allow the door panel to fully dry.



STEP 2

Locate the identification marks on the backside of each panel to determine mounting location. Once identified, peel the red tape backing from the double sided tape on the panel.





STEP 3

Adhere the panel to the bottom side of the interior door grab handle.



STEP 4

Repeat steps 1-3 to the remaining door.

Installation is now complete.