



UNDERHOOD INSULATION

(2021+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Insulation Panel
(13) Plastic Push Clips

TOOLS REQUIRED

N/A

STEP 1

Open the vehicle hood, and locate the (13) pre-drilled holes in the hood panel. The included push clips will be inserted into these holes.

STEP 2

Align the hood insulation to the vehicle, and secure into place using the included (13) plastic push clips.

Installation is now complete.