



XD1 BULL BAR

(2021+ BRONCO - WITH OEM MODULAR FRONT BUMPER)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Bull Bar
(8) Flat Washers

TOOLS REQUIRED

T-40 Torx Socket/Bit
Ratchet

**STEP 1**

Locate and remove the (8) T-40 Torx bolts from the front bumper.

**STEP 2**

Place the bull bar onto the bumper, ensuring the bull bar is flat on the bumper. Secure the bull bar using the (8) T-40 Torx bolts and (8) provided flat washers. Tighten until secure.

Note: If bull bar does not align over threaded inserts properly, tighten one side of the bull bar and pull the opposite side over the inserts, then tighten the bull bar on both sides.

Installation is now complete.