



FRAME PLUGS

(2021-2022+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Square Frame Plugs
(2) Rectangle Frame Plugs

TOOLS REQUIRED

15mm Socket
Ratchet
T-30 Torx Socket
Panel Removal Tool
Exterior Detailer (Optional)

STEP 1



Locate the crash bar behind the vehicle front wheel. Insert (1) square frame plug into the crash bar.

STEP 2



Plastic bumper: Remove the (2) front bumper caps using a panel removal tool to reveal the bumper mounting bolts.

Modular Bumper: Remove the end caps from the bumper. With the end caps removed, install the front crash bar plugs.



STEP 3

Remove the (6) 15mm bolts, and remove the bumper from the vehicle. Unplug the fog light harness.



STEP 4

Locate the front crash bar. Insert the front crash bar plugs. Once installed, re-install the vehicle bumper following steps 2-3 in reverse order.

Installation is now complete.