

SHORTY BULLET ANTENNA

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

TOOLS REQUIRED

10mm Wrench

SKU # FB20461 Edited: 11/11/2022



STEP 1



Twist the vehicle antenna counter clockwise to unthread the antenna from the vehicle cowl.



STEP 2

Thread the new antenna onto the vehicle cowl. Snug the antenna into place using a 10mm wrench. Installation is now complete.