



DEAD PEDAL COVER

(2021-2022+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Dead Pedal Cover

TOOLS REQUIRED

Isopropyl Alcohol
Microfiber Cloth

STEP 1



Clean the dead pedal surface using isopropyl alcohol and a microfiber cloth, and allow to fully dry. Peel the double sided tape backing from the back of the dead pedal cover.

STEP 2



Align the cover to the vehicle dead pedal. Ensure the cover is not overlapping the vehicle carpet. Firmly press the cover to the dead pedal to adhere the double sided tape.

Installation is now complete.