



# D-PILLAR COVER TRIM

(2021-2022+ BRONCO - 4 DOOR)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) LH D-Pillar Trim  
(1) RH D-Pillar Trim

### TOOLS REQUIRED

---

Isopropyl Alcohol  
Microfiber Cloth



## STEP 1

Access the rear roll bar, and clean the roll bar using isopropyl alcohol and a microfiber cloth. Once clean, ensure the roll bar is completely dry.



## STEP 2

Test fit the trim to the vehicle roll bar prior to peeling the red tape backing to familiarize fitment. Once familiar, peel the red tape backing from the double sided tape and adhere the trim to the roll bar. Press firmly to ensure proper adhesion.

Repeat steps 1-2 for the opposite side trim panel. Installation is now complete.