



# FRONT CORNER GUARDS

(2021-2022+ BRONCO)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Corner Guard
- (1) RH Corner Guard
- (2) Adhesion Promoter Pads

### TOOLS REQUIRED

---

N/A



## STEP 1

Clean the vehicle fender using the provided (1) adhesion promoter pad. Test fit the corner guard prior to removing the double sided tape to familiarize fitment to the vehicle.



## STEP 2

Once familiar with fitment on the vehicle, peel the red tape backing from the double sided tape. Align, then firmly press the corner guard to the vehicle fender. Ensure all areas of the corner guard are fully pressed to the vehicle to ensure proper adhesion.

Repeat steps 1-2 for the opposite side of the vehicle. Installation is now complete.