



PARACORD GRAB HANDLE

(2021-2022+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Paracord Grab Handle

TOOLS REQUIRED

8mm Socket
Ratchet

SKU # FB20478 / FB20479
/ FB20480 / FB20481
Edited: 05/25/2022



STEP 1

Along the roll bar, remove the (2) 8mm bolts above the vehicle door.



STEP 2

Place the grab handle to the bolt holes, and secure into place using the original (2) 8mm bolts. Tighten until secure.

Installation is now complete.