



Thank you for your business

Tools needed for install

- 5mm Allen wrench

In your kit

- 2 - Replacement PSD panels
- 2 - 3/8 Triangle shaped Spacers
- 2 - Color rings 2 - 3/8 triangled shaped covers.
- 12 - Socket head cap bolts



1. Remove your stock front door nets. Keep the bolts neat and you may want them. They are not needed in this installation.

2. Assemble on the bench first.3. Lay 1 triangled shaped spacer down on the bench. Lay PSD net on top of the spacer with holes lining up. Place a color ring around the outside of the net. Cover it with the file HDPE ring with countersunk hole facing up Smooth bullnose to outside facing out.4. Pick the entire assembly up. Place assembly onto the door using bolts to hold into place as you work around the assembly onto the door.



5. Repeat steps 1-4 for the other door. The PSD net will leave 3 to 4 inches between the door and seat for Molle pouches for storage.

If you have any questions contact us.

sales@orangeboxxfab.com

Our hours are Monday - Friday 9am - 4:30 pm eastern

Call us (336)804-0571

Tag us on Instagram

#orangeboxxfab