



CENTER CONSOLE WIRELESS CHARGING DOCK

(2021-2023+ BRONCO - AUTOMATIC TRANSMISSION)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Wireless Charging Module
- (1) 'T' Harness
- (1) Silicone Pad
- (1) Plastic Pry Tool

TOOLS REQUIRED

- T-20, T-30 Torx Sockets/Bits
- Ratchet
- Plastic Pry Tool (Provided)
- Short Phillips Screwdriver



STEP 1

Park the vehicle on a level surface with the parking brake engaged.

Remove (2) T-30 Torx bolts from the center console grab handle. Remove the grab handle from the center console and set aside. Retain the original hardware.



STEP 2

Work around the perimeter of the center console trim panel using the plastic panel tool to dislodge the retaining clips. Pull the center console towards the rear of the vehicle to dislodge the (2) front retaining clips.