



FOOT REST PEDAL SET - FRONT

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Foot Rest
- (1) RH Foot Rest
- (2) Tapered Allen Bolts
- (1) Allen Key

TOOLS REQUIRED

- 13mm Socket
- Ratchet
- 4mm Allen Key (Provided)



STEP 1

Remove the vehicle front door following the OEM removal procedure.



STEP 2

Place the (1) foot rest onto the top of the vehicle lower door hinge. Secure the foot rest into place using (1) tapered Allen bolt. Tighten until secure.



STEP 3

Pivot the foot rest outwards to use, and pivot inwards to store when not in use.

Installation is now complete.