



FENDER FLARES

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Fender Flare
- (1) RH Front Fender Flare
- (1) LH Rear Fender Flare
- (1) RH Rear Fender Flare

TOOLS REQUIRED

Flathead Screwdriver



STEP 1

Locate the vehicle fender flare, and turn the (5) latches attaching the original fender flare to the vehicle.



STEP 2

After turning the latches, firmly pull the original fender flare away from the vehicle.

Place the original fender flare on a soft surface for disassembly.

**STEP 3**

Place the new corresponding fender flare on a soft surface for assembly.

Using a flathead screwdriver, press the (2) tabs on each side of the fender flare latches. Transfer the latches to the new fender flare. Transfer the original fender flare push clips to the new fender flare. Use a flathead screwdriver to push the push clips downwards to fully secure the clips into the new fender flare.

**STEP 4**

With the clips transferred, push the fender flare into place on the vehicle. Turn the (5) latches to secure the fender flare into place.

Repeat steps 1-4 for the remaining fender flares. Installation is now complete.