



TOP DRIP TRAYS

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Drip Tray
- (1) LH Rear Drip Tray
- (1) RH Front Drip Tray
- (1) RH Rear Drip Tray

TOOLS REQUIRED

- Isopropyl Alcohol
- Microfiber Cloth



STEP 1 (FRONT)

Retract/remove the vehicle top to gain access to the upper door surround.

Clean the designated area of the vehicle using isopropyl alcohol and a microfiber cloth and allow to fully dry.



STEP 2 (FRONT)

Peel the red double sided tape backing from the drip tray, and align the panel to the vehicle.

Note: Lift the windshield weatherstripping slightly to route the tray under, then once the tray is in place, allow the weatherstripping to lay flat over the tray.



STEP 3 (REAR)

Retract/remove the vehicle top to gain access to the upper door surround.

Clean the designated area of the vehicle using isopropyl alcohol and a microfiber cloth and allow to fully dry.



STEP 4 (REAR)

Peel the red double sided tape backing from the drip tray, and align the panel to the vehicle. Fit the tray in-line with the front drip tray, then firmly press the tray into place.

Repeat steps 1-4 to the opposite side of the vehicle, then re-install the vehicle top to the vehicle following OEM specification. Installation is now complete.