

TRUNK 'T' HOOKS

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH 'T' Hook

(1) RH 'T' Hook

TOOLS REQUIRED

T-30 Torx Socket Ratchet





STEP 1

In the trunk/cargo area, remove (1) T-30 Torx bolt from the rear roll bar.



STEP 2

Identify the 'T' hooks, each hook is vehicle side specific. See the diagram above to identify.





STEP 3

Align the hook to the vehicle, and secure the hook into place using the original (1) T-30 Torx bolt. Tighten until secure.



STEP 4

Repeat steps 1-3 for the remaining hook.

Installation is now complete.