



# PARACORD GRAB HANDLES

(2021-2023+ BRONCO)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(4) Paracord Grab Handles

### TOOLS REQUIRED

---

8mm Socket  
Ratchet

SKU # FB26824  
Edited: 02/10/2023



## STEP 1

Along the roll bar, remove the (2) 8mm bolts above the vehicle door.



## STEP 2

Place the grab handle to the bolt holes, and secure into place using the original (2) 8mm bolts. Tighten until secure.

Installation is now complete.