



GRAB HANDLES

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

(4) Grab Handles

TOOLS REQUIRED

8mm Socket
Ratchet



STEP 1

Along the roll bar, remove the (2) 8mm bolts above the vehicle door.



STEP 2

Place the grab handle to the bolt holes, and secure into place using the original (2) 8mm bolts. Tighten until secure.

Installation is now complete.