



DOOR HINGE FOOT REST WITH USA FLAG

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Foot Rest
- (1) RH Foot Rest

TOOLS REQUIRED

13mm Wrench



STEP 1

Remove the vehicle door following OEM door removal procedure. Ensure to retain the original mounting hardware.



STEP 2

Place the (1) foot rest onto the top of the vehicle lower door hinge. Secure the foot rest into place using the short OEM door hinge bolt. Tighten until secure.



STEP 3

Pivot the foot rest outwards to use, and pivot inwards to store when not in use.

Repeat steps 1-3 for the remaining foot rest. Installation is now complete.