



HEAVY DUTY TPE CARGO LINER

(2021-2023+ BRONCO - 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Cargo Liner

TOOLS REQUIRED

Vacuum Cleaner (Optional)

STEP 1



Clean the vehicle cargo area using a vacuum cleaner, if desired. Pull each anchor point to the vertical position.

STEP 2



Identify the front of the cargo liner by looking at each corner. The corners will match the vehicle interior panels.



STEP 3

Place the cargo liner into the vehicle cargo area, ensuring all anchor points are fitted through the liner. When not using the anchor points, the liner can be lifted and the anchor points can rest under the liner.

Installation is now complete.