



REAR SPOILER

(2021-2023+ BRONCO - WITH OEM HARD TOP)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Rear Spoiler
- (2) Adhesion Promoter Pads
- (1) Alcohol Prep Pads

TOOLS REQUIRED

N/A



STEP 1

Clean the vehicle hard top first with the (2) alcohol prep pads and allow to fully dry. Then, clean the same area using the (2) adhesion promoter pads and allow to fully dry.



STEP 2

Test fit the spoiler to the vehicle prior to removing the red tape backing to familiarize fitment. Once familiar, peel the red tape backing and firmly press the spoiler to the vehicle hard top.

Installation is now complete.