



MULTI-FUNCTION PHONE MOUNT

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Picatinny Rail
- (1) LH Rail Mount
- (1) RH Rail Mount
- (1) Center Rail Mount
- (1) Ball Mount Holder
- (1) Phone Holder
- (1) Camera Holder
- (1) Picatinny Rail Ball Mount
- (2) M6 x 10mm Conical Allen Bolts
- (1) M6 x 25mm Conical Allen Bolts
- (1) Allen Key

TOOLS REQUIRED

- 5mm Allen Key (Provided)
- Isopropyl Alcohol
- Microfiber Cloth

SKU # FB28757
Edited: 02/09/2023



STEP 1

Using the (1) center rail mount, (1) picatinny rail, and (1) M6 x 25mm Allen bolt, loosely secure the picatinny rail to the vehicle dashboard. The Allen bolt will fit through the rail and the mount into the vehicle threaded insert.



STEP 2

Using isopropyl alcohol and a microfiber cloth, clean the dashboard under each side of the picatinny rail. Then, peel the attached double sided tape on each side mount, and secure the mounts under the rail to the dashboard. Once the mounts are secure, bolt the rail to the mount using (1) M6 x 10mm bolt per side.



STEP 3

Assemble the picatinny rail ball mount and the phone ball mount onto the ball mount holder.



STEP 4

Slide each mount into the picatinny rail, and tighten the thumb screws until secure in the desired location.

Installation is now complete.