



ARM REST STORAGE TRAY SET

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Upper Storage Tray
(1) Lower Storage Tray

TOOLS REQUIRED

N/A

STEP 1



Clean the center console of its contents. Place the lower storage tray into the center console. The tray will fit within the grooves in the center console.

STEP 2



Place the upper storage tray on top of the lower storage tray. Close the center console lid to confirm fitment.

Installation is now complete.