



# TELESCOPIC WINDOW CURTAINS

(2021-2023+ BRONCO - 4 DOOR)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(2) Front Window Shades [LH & RH]  
(2) Rear Window Shades [LH & RH]  
(4) Retainer Clips

### TOOLS REQUIRED

---

Isopropyl Alcohol  
Microfiber Cloth

## STEP 1



Lower the vehicle window. By hand, unroll each window shade to confirm proper vehicle fitment. The front shades will allow visibility to the side mirrors, the rear shades will cover the entire window.

Clean the top of the door panel using isopropyl alcohol and a microfiber cloth, and allow to fully dry. Then, peel the tape backing and firmly adhere the base of the window shade to the door panel.

## STEP 2



Partially raise the vehicle window. Hook the window shade to the top edge of the window, the shade will not raise/lower with the glass.

Alternatively, the shade can be operated independently of the glass by adhering the provided retaining clip to the vehicle roll bar panel.

Installation is now complete.