



FRONT FENDER FLARE EXTENSIONS

(2021-2023+ BRONCO WITH MODULAR FRONT BUMPER
& WITHOUT SASQUATCH PACKAGE)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Flare Extension
(1) RH Flare Extension

TOOLS REQUIRED

T-40 Torx Socket
Ratchet



STEP 1

Remove the (2) T-40 Torx bolts from the vehicle modular front bumper.



STEP 2

Fit the designated flare extension to the bumper bolt holes, and secure into place using the original (2) T-40 Torx bolts, tighten each bolt evenly until the extension is secure.

Repeat steps 1-2 for the remaining flare extension. Installation is now complete.