



DRIVER SIDE DASHBOARD PHONE MOUNT

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Dashboard Mounting Bracket
- (1) Phone Clamp
- (1) Double Ball Mount Clamp
- (1) Ball Mount Fitting
- (2) Allen Bolts
- (1) Allen Key

TOOLS REQUIRED

- T-30 Torx Key



STEP 1

Remove (2) T-30 Torx bolts from the vehicle dashboard grab handle.

Note: OEM hardware will not be reused.



STEP 2

Align the dashboard mounting bracket to the dashboard, and secure into place using the (2) Allen bolts. Tighten the hardware evenly until secure.

STEP 3



Loosen the (1) thumb screw, and fit the double ball mount clamp around the ball mount on the dashboard mounting bracket. Then, adjust to the desired position and tighten the thumb screw.

STEP 4



Loosen the (1) thumb screw, and fit the ball mount into the double ball mount clamp.



STEP 5

Fit the (1) phone mounting clamp nut onto the previously mounted ball mount, then clip the phone mount onto the ball mount. Secure the phone mount to the ball mount by threading the nut until the phone mount is secure.



STEP 6

From the driver's seat, position the phone mount to the desired angle, and tighten all adjustment point until the mount is secure into place.

Installation is now complete.