



SMOKED GRILLE SIDE MARKER LAMP COVERS

(2021-2023+ BRONCO - WITH OEM MIRROR LIGHTS)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Light Cover
- (1) RH Light Cover
- (2) Alcohol Prep Pads

TOOLS REQUIRED

N/A



STEP 1

Clean the grille marker light using (1) alcohol prep pad, and allow the light to fully dry.

Test fit the light cover prior to removing the tape backing to familiarize fitment.



STEP 2

Peel the red tape backing from the light cover, and firmly press the cover to the vehicle grille marker light.

Repeat steps 1-2 for the remaining light cover.

Installation is now complete.