



# SMOKED SIDE MIRROR TURN SIGNAL COVERS

(2021-2023+ BRONCO - WITH OEM MIRROR LIGHTS)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Light Cover
- (1) RH Light Cover
- (2) Alcohol Prep Pads

### TOOLS REQUIRED

---

N/A



## STEP 1

Clean the mirror light housing attached to the mirror using (1) alcohol prep pad, and allow the light to fully dry.

Test fit the light cover prior to removing the tape backing to familiarize fitment.



## STEP 2

Peel the red tape backing from the light cover, and firmly press the cover to the vehicle mirror light.

Repeat steps 1-2 for the remaining mirror light.

Installation is now complete.