



# SMOKED THIRD BRAKE LIGHT COVER

(2021-2023+ BRONCO)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Third Brake Light Cover  
(1) Alcohol Prep Pad

### TOOLS REQUIRED

---

N/A



## STEP 1

Clean the third brake light lens using (1) alcohol prep pad, and allow the light to fully dry.

Test fit the light cover prior to removing the tape backing to familiarize fitment.



## STEP 2

Peel the red tape backing from the light cover, and firmly press the cover to the vehicle third brake light.

Installation is now complete.