



REAR DEFROST ELEMENT PROTECTOR TRIM

(2021-2023+ BRONCO - WITH HARDTOP)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Trim Cover
- (1) RH Trim Cover
- (2) Alcohol Prep Pads
- (2) Adhesion Promoter Prep Pads

TOOLS REQUIRED

N/A

STEP 1



Open the vehicle tailgate and rear window, locate the rear window defroster.

Using the included (1) alcohol prep pad, clean the indicated area of the window and allow to fully dry.

Then, using the included (1) adhesion promoter prep pad, clean the indicated area of the window and allow to fully dry.

STEP 2



Test fit the trim panel vehicle glass before removing the double sided tape backing. The tape will adhere to the rear window. Once familiar with fitment, peel the red tape backing from the trim panel. Firmly press the trim panel into the glass to encourage tape adhesion.

Repeat steps 1-2 for the remaining trim panel.

Installation is now complete.