



UNDER SEAT VENT GRILLES

(2021-2023+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Vent Grilles
(2) Alcohol Prep Pads
(2) Adhesion Promoter Prep
Pads

TOOLS REQUIRED

N/A



STEP 1

Slide the front seat forward, and locate the floor air duct.

Using the included (1) alcohol prep pad, clean the top of the air duct and allow to fully dry. Then, using the included (1) adhesion promoter prep pad, clean the top of the air duct and allow to fully dry.



STEP 2

Test fit the grille to the air duct before removing the double sided tape backing. The tape will adhere to the top of the air duct. Once familiar with fitment, peel the red tape backing from the grille. Firmly press the grille to the air duct to encourage tape adhesion.

Repeat steps 1-2 for the remaining air duct grille.

Installation is now complete.