



# A-PILLAR OFFROAD LIGHT BRACKETS

(2021-2024+ BRONCO)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Upper Bracket
- (1) LH Lower Bracket
- (1) RH Upper Bracket
- (1) RH Lower Bracket

### TOOLS REQUIRED

---

- T-25, T-30 Torx Sockets
- Ratchet



## STEP 1

Locate the ACCESSORY READY mount along the windshield cowl in front of the A-Pillar. Remove (1) T-25 Torx bolt and (1) T-30 Torx bolt from the windshield cowl mount.

Note: Removing the radio antenna by twisting counter-clockwise can aid installation, but is not required.



## STEP 2

Align the appropriate lower mounting bracket to the vehicle windshield cowl. Secure the bracket into place using the original Torx bolts. Tighten the hardware evenly until secure.



---

## STEP 3

Place the (1) upper mounting bracket onto the previously mounted lower bracket, aligning the pod light bolt holes.

Install pod lights (sold separately) to the bracket assembly and secure using pod light mounting hardware.

Repeat steps 1-3 for the opposite side of the vehicle. Installation is now complete.