



TAILGATE MOUNTED FOLDABLE REAR STEP

(2021-2024+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Step Assembly
- (1) Lower Bracket
- (1) Upper Bracket
- (2) Rubber Gaskets
- (4) M8x1.25 x 45mm Allen Bolts
- (4) M8x1.25 x 25mm Allen Bolts
- (8) M8 Lock Washers
- (8) M8 Flat Washers

TOOLS REQUIRED

- T-45 Torx Socket
- 5mm Allen Key/Socket
- Ratchet
- Isopropyl Alcohol
- Exterior Detailer
- Microfiber Cloth

SKU # FB39828
Edited: 02/13/2024



STEP 1

Identify the included step mounting brackets on a workable surface.

Turn the brackets to allow the tailgate mounting portion to face upwards. Clean the area with isopropyl alcohol and a microfiber cloth. Then, adhere the included (2) rubber gaskets to the mounting brackets. The gaskets will protect the vehicle tailgate hinge paint.



STEP 2

Remove (2) T-45 Torx bolts from the upper mounting bracket.

Note: Do not remove all tailgate hinge bolts. Removing all bolts will affect tailgate alignment.

STEP 3



Secure the upper mounting bracket to vehicle tailgate hinge using (2) M8 x 45mm Allen bolts. Tighten the bolts evenly until secure.

STEP 4



With the top bracket secure, remove the (2) lower hinge T-45 bolts. Secure the mounting bracket to the vehicle tailgate over the vehicle tailgate hinge using (2) M8 x 45mm Allen bolts. Tighten the bolts evenly until secure.

STEP 5



Secure the step assembly to the mounting brackets using (4) M8 x 25mm Allen bolts, (4) M8 lock washer, and (4) M8 flat washers.

STEP 6



Ensure all hardware is secure. Fold the step pegs down to utilize the steps. Fold the step pegs upwards when not in use.

Installation is now complete.