



OE STYLE WIDE FENDER FLARES

(2021-2024+ BRONCO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Flare
- (1) RH Front Flare
- (1) LH Rear Flare
- (1) RH Rear Flare
- (24) 90-degree Clips
- (24) Push Clips

TOOLS REQUIRED

- Exterior Detailer
- Microfiber Cloth



STEP 1

From under the fender flare, locate the (5) 90-degree clips. Turn the clips 90-degrees to disengage from the vehicle fender.

With all clips turned, firmly pull the fender flare away from the vehicle to dislodge the retaining clips.



STEP 2

Fit the included push clips into the slots in the fender flare, and slide the clip downwards to engage the clip into the flare.

Note: Ensure the clip faces the outside of the flare to engage the vehicle body.

STEP 3



Press the flare to the vehicle to engage the previously installed clips to the vehicle fender. Then, while holding the flare into place, secure the flare to the vehicle using the included (5) 90-degree clips.

STEP 4



Repeat steps 1-3 for all remaining fender flares.

Installation is now complete.