



BULL BAR

(2021-2024+ BRONCO - WITH OEM MODULAR FRONT BUMPER)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Bull Bar
(8) Flat Washers

TOOLS REQUIRED

T-40 Torx Socket
Ratchet



STEP 1

Remove the (4) T-40 Torx bolts in the vehicle front bumper.

The bolts will be reused.



STEP 2

Install the included foam pads to be base of the bull bar using foam pad tape backing.



STEP 3

Fit the included (8) flat washers onto each of the vehicle T-40 Torx bolts. Then, fit the bull bar to the vehicle using the (8) T-40 Torx bolts and the (8) flat washers. Tighten the hardware evenly until the bull bar is secure.

Installation is now complete.