



Installation Guide

Raptor Style LED Tail Lights
For 2021-2023 Ford Bronco

SKU # AMFMEC00202

STEP 1



Remove the 3 Philips retaining clips, then remove the 5 clips to remove your fender flare. Put your fingers underneath that little flap and pull the panel toward you.

STEP 2



Remove the 10 mm bolt, then reach your hand behind and pull the panel outwards. Remove the two 8 mm bolts, then remove the 10 mm bolt on the upper left hand, pull the tail light outwards and unclip the OEM harness.

STEP 3



Remove the four 7 mm bolts to remove the backing plate and transfer it to the new tail lights. Remove the OEM connector from the mounting. After the backing plate being installed into the new tail light, (1)For Stock LED Taillights, please plug to the OEM taillights plug with the wiring harness; (2)For Stock Halogen Taillights, Please refer to the wiring diagram insctrucions.

STEP 4



Follow the step 1-2 in reverse order to reinstall all the bolts to the vehicle to complete the installation.