

EA12-M1 Installation Instructions

Step 1: Using an 18mm socket or wrench, remove the 2 screws from the bottom of the bumper.



Step 2: Align the tow loop and spacer plate with mounting holes and start the screws. Note the position of the spacer plate between tow loop and bumper.



Step 3: Tighten the screws.



Step 4: Repeat on the other side.