

# LED TAIL LIGHTS

## (2021-2025+ BRONCO-WITH OEM HALOGEN TAIL LIGHTS)

### INSTALLATION INSTRUCTIONS

#### CONTENTS

- (1) LH Tail Light
- (1) RH Tail Light

#### TOOLS REQUIRED

- 8mm, 10mm Sockets
- Ratchet with Extension
- Phillips Screwdriver
- Plastic Pry Tool
- Panel Removal Tool



STEP 1

Remove (4) Phillips head plastic push clips. Loosen the Phillips head inner portion of the clip, then pull the plastic clip body out of the vehicle.

Note: Add pressure under the plastic clip body to allow the inner portion of the clip to move outwards, if necessary.



STEP 2

Remove (2) 10mm screws from the tailgate trim panel. Remove the trim panel from the vehicle, and set aside.



STEP 3

In between the vehicle body and the rear bumper, remove (1) 10mm bolt.



STEP 4

Using a plastic pry tool, pull the vertical section of the tail light trim outwards.



STEP 5

Pull outwards on the horizontal portion of the tail light trim, then pull upwards to remove the trim from the vehicle.

Note: Loosening the rear-most latch on the fender flare and pulling the rear of the fender flare away from the vehicle can be done to provide additional space for the tail light trim if necessary.



STEP 6

Remove (1) 10mm bolt from the outside of the tail light assembly.



STEP 7

Remove (2) 8mm bolts from the inside of the tail light assembly. Firmly pull the tail light assembly away from the vehicle body to dislodge the alignment pin.



STEP 8

Unplug the tail light connector from the tail light by pressing the plastic push tap, and remove the tail light from the vehicle.



STEP 9

Identify the LH / RH tail lights using the embossed label in the back of the tail light housings. Plug the tail light into the vehicle harness, and mount the tail light to the vehicle reusing the original tail light mounting hardware.



STEP 10

Install the tail light trim panels to the vehicle reusing the original hardware.

Repeat Steps 1-10 for the remaining tail light.

Installation is now complete.