

# MAXIMUS-3



## FORD BRONCO PERIPHERAL LIGHT BRACKETS PART # BR1006PL

### INSTALLATION GUIDE

Please make sure you read and understand the entire installation guide before you start. We expect you to have basic mechanical abilities to perform this installation.

We recommend that you separate and identify all the parts and hardware kits you received with your shipment before you proceed to disassemble your Jeep.

<u>PARTS LIST:</u>	<u>QTY</u>
PERIPHERAL LIGHT BRACKET	2
HARDWARE KIT	1

### INSTALL STEPS

- 1) Remove T30 Factory Bolts
- 2) Place brackets and align in location shown below. Note: LHS and RHS Brackets
- 3) Bolt brackets down using Factory Hardware or Hardware supplied.
- 4) Bolt your lights to the Brackets and wire as desired or follow the lights instructions.

