

Thanks for choosing a KC HiLiTES product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 800-528-0950. **For warranty information, visit our website at www.kchilites.com.**

NOTE - This bracket set is designed for the KC 338 50" LED bar only.

PARTS INCLUDED

- 1 - 50" LED light bar with wiring (KC #338)
- 1 - Above windshield light mounting bracket set
- 10 - M8 x 1.25 x 30 mm Black Zinc Bolts
- 10 - M8 Black Zinc Washers
- 2 - Protective Rubber Gaskets

MOUNTING THE BRACKETS

1. Remove the upper five of the six torx head bolts from each of the windshield frame brackets. These are located in the lower corner of the driver and passenger side of the windshield.
2. Align the rubber protective gasket with the holes on the vehicle and secure temporarily with small pieces of scotch tape or similar.
3. Place the bracket on the gasket and start each of the five M8 bolts and washers. Tighten all by hand. Remove the tape used to secure and then tighten all bolts.
4. Repeat procedure for opposite side of vehicle.
5. Install your 50" C50 LED bar to the brackets and wire it according to the instructions included with the LED bar.

YOU'RE DONE

