

## PRODUCT INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering, Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

**DESCRIPTION:** Universal Muffler Shield Kit

**PART NUMBER:** 010455

**APPLICATION(s):** Supplemental heat shield for mufflers


**KIT CONTENTS:**

Extreme Heat Barrier insulation material (1)


Stainless Steel Locking Ties (2)

Locking Tie Tool (1)

**TOOLS NEEDED:** ¼" drive handle or ratcheting socket driver, ¼" extension (optional), side cutters, safety glasses, gloves, and heavy duty scissors

**ADDITIONAL INFORMATION:**  Always wear safety glasses, gloves and long sleeve clothing when handling this product



1.  Take care when handling the Heat Barrier material as the edges may be sharp.
2. Measure the body of the muffler to be wrapped.
3. You can either overlap the shield on your muffler or butt the shield at the seam for a cleaner look.
4. Transfer the measurement to the shield and use your scissors to cut the shield to fit.
5. For best results, arrange the seam so it is on the top of the muffler.
6. Wrap the shield around the muffler with glass fiber side toward the muffler, and secure using the supplied 40" stainless ties.
7. Use the supplied Locking Tie Tool to make installation quick and easy. Refer to separate Locking Tie Tool instructions for use.
8. Trim excess tie using side cutters, fold under, and crimp.