

DIRECT-REPLACEMENT  
**INTERNAL BYPASS SHOCKS**  
INSTALLATION GUIDE



**JEEP JK (07+)**

883-02-068 - 2.5 FACTORY SERIES Internal Bypass Kit

883-02-069 - 2.5 FACTORY SERIES Internal Bypass Kit



## INSTALLATION GUIDE

### JEEP JK

2.5 FACTORY SERIES Internal Bypass Kit:  
883-02-068\*\*

2.5 FACTORY SERIES Internal Bypass Kit:  
883-02-069

\*\* Fox recommends using an aftermarket lower mount relocation bracket to ensure that the 2.5 shock body does not interfere with the vehicle frame at full articulation.

Thank you for choosing FOX direct-replacement shocks for your vehicle.

FOX products are designed, tested, and manufactured by the finest professionals in the industry.

FOX recommends that you become completely familiar with the handling characteristics of your modified vehicle before operating it under rigorous conditions, helping to avoid potential rollover situations and other loss of control events. FOX further recommends that you use appropriate protective equipment at all times when operating your vehicle.

To achieve the best performance and product longevity, periodic service and maintenance is required. Please refer to the Service and Upgrades section for more information.

## WARNINGS

- FOX direct-replacement shocks are designed to fit and allow proper clearance with the factory suspension. If aftermarket suspension components are installed it is the customers responsibility to ensure that at full cycle the suspension clears the FOX shocks.
- FOX direct-replacement shocks should always be installed as a pair for maximum performance.
- Proper installation and service procedures are essential for the safe and reliable installation of chassis parts, requiring the experience and tools specially designed for this purpose. Installation and maintenance procedures for this product must be performed by a qualified service technician, to avoid potentially unsafe vehicle handling characteristics, which may result in **SERIOUS INJURY** or **DEATH**.
- Modifying your vehicle's suspension will change the handling characteristics of your vehicle. Under certain conditions, your modified vehicle may be more susceptible to loss of control or rollover, which can result in **SERIOUS INJURY**

or **DEATH**. Thoroughly familiarize yourself with the modified vehicle handling characteristics before any rigorous vehicle operation. Wear body protective gear including head protection when appropriate. Installation of vehicle roll bars or cage is highly recommended.

- FOX direct-replacement shocks are gas-charged and are highly pressurized. Placing shocks in a vise or clamp, applying heat, or attempting to open or service the shock without the proper tools and training can result in **SERIOUS INJURY** or **DEATH**. Do not attempt to modify, puncture or incinerate a FOX direct-replacement Intenal Bypass shock absorber.
- Any attempt to misuse, misapply, modify, or tamper with any FOX product voids any warranty and may result in **SERIOUS INJURY** or **DEATH**.

## GUIDELINES

- Always use a chassis lift for the installation of shocks, and make certain that the raised vehicle is securely attached to the lift to prevent the



vehicle from slipping, falling, or moving during the installation process.

- DO NOT install any FOX product without the necessary special tools, expertise and chassis lift, or you will subject yourself to the risk of SERIOUS INJURY or DEATH. If you elect to not use a chassis lift (which election may result in SERIOUS INJURY or DEATH), ensure that the vehicle is on level ground, that all tires on the ground during installation are blocked to prevent vehicle movement, that at least two tires are on the ground at all times, and that adequately secured jack stands are used to support the vehicle. NEVER get under the vehicle until you have checked to ensure that the vehicle will be stable during installation.
- FOX direct-replacement shocks are designed to fit your vehicle's shock mounts with no modifications with the exception of reservoir placement on specific models and applications.

## INSTRUCTIONS - FRONT

Medium-strength thread-lock (blue Loctite) is recommended on all bolts.

1. Please read the INSTALLATION GUIDELINES for instructions on how to properly lift and secure the vehicle.
2. Remove front wheels.
3. Remove front stock shocks.
4. Install the supplied reservoir brackets to the vehicle frame so that brackets angle up toward the rear of the vehicle. The FOX reservoir brackets have cutouts to locate around the tube coming from the vehicle frame. Mark the center hole and drill a 21/64" pilot hole then secure the reservoir bracket to the frame with one of the supplied 3/8" self tapping screws. Drill the remaining two pilot holes and install self tapping screws (Fig. 1).
5. If an aftermarket lower relocation bracket will be used install per manufactures instructions at this time (Fig.2).
6. Connect the FOX shock to the top vehicle mount with a stem bushing and washer on the bottom and top. Tighten top



Fig. 1: Driver side



Fig. 2: Driver side

locking nut until 5/8" of total stem is showing (Fig. 3).

7. Connect the Fox Shock to the lower mount using the factory nut and bolt. Torque to factory specifications. If using an aftermarket relocation



bracket consult manufacture instructions (Fig. 3).

- Using two supplied clamps, mount the reservoir to the brackets. Utilize the slots in the bracket to locate clamps. Do not feed the clamps through the slots in the brackets (Fig. 4).



Fig. 3: Driver side

- Check that the suspension has proper clearance by steering completely in both directions.
- Reinstall both front wheels and torque to factory specifications.
- For maximum performance of your new Internal Bypass Shocks, Fox recommends at ride height that there be between 5.50" to 7.75" of shaft showing.




Fig. 4: Driver side

## INSTRUCTIONS - REAR

Medium-strength thread-lock (blue Loctite) is recommended on all bolts.

1. Please read the INSTALLATION GUIDELINES for instructions on how to properly lift and secure the vehicle.
2. Remove rear wheels.
3. Remove the stock shocks.
4. Reusing the factory nuts and bolts, install the new FOX shock with the reservoir pointing towards the rear and angled outwards (Fig. 5). Torque to factory specifications
5. If the reservoir does not clear suspension, use the FOX supplied spanner wrench with a standard 3/8" ratchet to loosen piggyback lock ring. Once loosed you can rotate reservoir as needed without losing nitrogen or oil (Fig. 6, 7, & 8).
6. Check that the suspension has proper clearance.
7. Reinstall both rear wheels and torque to factory specifications.
8. For maximum performance of your new Internal Bypass shocks, FOX recommends at ride height that there

be between 5.50" to 7.75" of shaft showing.



Fig. 5: Driver side



Fig. 6: Spanner wrench



Fig. 8: Spanner wrench tighten



Fig. 7: Spanner wrench loosen



## **FOX LIMITED WARRANTY**

FOX Factory, Inc., a California corporation having offices at 130 Hangar Way, Watsonville, CA 95076 ("FOX"), makes the following LIMITED WARRANTY with respect to its suspension products:

### **LIMITED ONE (1) YEAR WARRANTY ON SUSPENSION PRODUCTS**

Subject to the limitations, terms and conditions hereof, FOX warrants, to the original retail owner of each new FOX suspension product, that the FOX suspension product, when new, is free from defects in materials and workmanship. Unless otherwise required by law, this warranty expires one (1) year from the date of the original FOX suspension product retail purchase from an authorized FOX dealer or from a FOX authorized Original Equipment Manufacturer where FOX suspension is included as original equipment on a purchased vehicle. If law requires a warranty duration of greater than one (1) year, then, subject to the other provisions hereof, this warranty will expire at the end of the minimum warranty period required by such law.

## **TERMS OF WARRANTY**

This warranty is conditioned on the FOX suspension product being operated under normal conditions and properly maintained as specified by FOX. This warranty is only applicable to FOX suspensions purchased new from an authorized FOX source and is made only to the original retail owner of the new FOX suspension product and is not transferable to subsequent owners. This warranty is void if the FOX suspension product is subjected to abuse, neglect, improper or unauthorized repair, improper or unauthorized service or maintenance, alteration, modification, accident or other abnormal, excessive, or improper use.

Should it be determined by FOX in its sole and final discretion, that a FOX suspension product is covered by this warranty, it will be repaired or replaced, by a comparable model, at FOX's sole option, which will be conclusive and binding. **THIS IS THE EXCLUSIVE REMEDY UNDER THIS WARRANTY. ANY AND ALL OTHER REMEDIES AND DAMAGES THAT MAY OTHERWISE BE APPLICABLE ARE EXCLUDED, INCLUDING, BUT NOT LIMITED TO,**



INCIDENTAL OR CONSEQUENTIAL DAMAGES OR PUNATIVE DAMAGES.

This limited warranty does not apply to normal wear and tear, malfunctions or failures that result from abuse, improper assembly, neglect, alteration, improper maintenance, crash, misuse or collision. This limited warranty gives the consumer specific legal rights. The consumer may also have other legal rights which vary from state to state or country to country. Some states and countries do not allow the exclusion or limitation of incidental or consequential damages or warranties, and if dictated by law the above limitations or exclusions may not apply to you. If it is determined by a court of competent jurisdiction that a certain provision of this limited warranty does not apply, such determination shall not affect any other provision of this limited warranty and all other provisions shall remain in full effect.

THIS IS THE ONLY WARRANTY MADE BY FOX ON ITS SUSPENSION PRODUCTS AND COMPONENTS, AND THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION HEREIN. ANY WARRANTIES THAT MAY OTHERWISE BE IMPLIED BY

LAW INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXCLUDED.

# SHOX NEED ♥ TOO

## SERVICE & UPGRADES

Have your FOX serviced or upgraded by FOX technicians. Call our Offroad and Truck Service Center at 619.768.1800 to go over the service and upgrade options available for your shocks. Once you've setup your service or upgrades you will receive a return authorization number and shipping instructions.

## SERVICE INTERVALS

- 100% street use: every 50,000 miles
- 50% street / 50% offroad use:  
every 10,000 miles

## SERVICE MENUS & PRICING

Please visit [foxshox.info/orservice](https://foxshox.info/orservice)



# STAY INFORMED

## REGISTER YOUR PRODUCT



- 1 Create your personal profile
- 2 Let us know which products you own
- 3 Receive special offers on service, upgrades, and product



RIDEFOX.COM 750 VERNON WAY SUITE 101. EL CAJON, CA 92020 USA  
1.800.FOX.SHOX (369.7469) 619.768.1800 ORSERVICE@RIDEFOX.COM

PN 605-01-081 REV A JANUARY 2013