



Are your GraBars genuine?

We are proudly made in the USA by skilled American workers for fellow hardworking Americans. If your handles didn't come from us, then you likely have an inferior product that may have quality, safety, or installation concerns. Thanks for buying Genuine American made GraBars!

REAR GRABARS INSTALLATION FOR JK SERIES (2DR & 4DR)

Step 1:

Remove the (2) 6mm bolts on the bottom side of the roll bar using a 10mm socket.

Step 2:

NOTE: We recommend adding a drop of lubricating oil to the bolts before installing to help remove the thread locker Jeep puts in the threads from the factory.

Install the rear handle with the bend facing the front of the Jeep using the (2) M6 bolts supplied with your order. It works best if you install the front bolt first only threading in a few turns, then install the rear bolt and using a 5mm hex wrench, tighten both bolts to 120 in-lbs of torque.

Repeat steps 1 & 2 for the other side.

