



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS



REAR HITCH UTILITY STEP & LEDs

Z390010 / Z390010-KIT / Z390011 / Z390011-KIT

UNIVERSAL HITCH MOUNTED UTILITY STEP & LEDs

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.

PARTS INCLUDED

- (1) Hitch Mounted Step & LED Light Enclosure



LED LIGHTS INCLUDED

- Z390010** - No LED Lights Included
 - Z390011** - No LED Lights Included
 - Z390010-KIT** - (2) 3" LED Light Pods Included
 - Z390011-KIT** - (2) 3" LED Light Pods Included
- * LED Lights include a separate hardware kit.

HARDWARE INCLUDED

- Z390010** - No Hardware Included
- Z390011** - No Hardware Included
- Z390010-KIT** - LED Lights include a separate hardware kit.
- Z390011-KIT** - LED Lights include a separate hardware kit.

TOOLS REQUIRED

- BASIC Tools

INSTALLATION GUIDE

START HERE

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS.
* IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR MODEL OR PART.

BEFORE YOU BEGIN

START HERE: Turn off engine, chalk tires with stop block, open the hood and disconnect the battery.

LED LIGHT BRACKET INSTALLATION

STEP 1

SEE FIGURE 1

1) Take the ZROADZ Hitch Mounted Utility Step & LED Light Enclosure and place the Hitch Male insert into the Hitch Female Receiver. Please pin to lock and secure in place.

Make sure that your Hitch receiver is the correct size (2" = 2" / 2.5" = 2.5") for the ZROADZ Hitch Mounted Utility Step & LED Light Enclosure.



FIG 1