

**Design Engineering, Inc.**

604 Moore Road  
Avon Lake, OH 44012



*THERMAL TUNING PRODUCTS*

**Installation Instructions**

**DEI Boom Mat™ Speaker Baffles**

PART NO. 050300 through 050381

KIT CHECKLIST	
PN #	Speaker Baffles

NOTE
Materials needed - Pen, Scissors, knife, awl and Silicone Sealant

**DIRECTIONS**

- 1 - Tools Needed for install: Pen, Scissors, knife, awl and Silicone Sealant. (Fig 1)
- 2 - Test fit the speaker into the baffle. (Fig 2)
- 3 - Gently trace around carriage onto the baffle. (Fig 3)
- 4 - Remove speaker and baffle and carefully cut baffle on traced line using sharp scissors. (Fig 4)
- 5 - Replace speaker into baffle and perforate screw holes using an awl or other pointed tool. Use care not to tear the baffle material. (Fig 5)
- 6 - To install speaker wire it may be necessary to penetrate the baffle housing to route the wire. (Fig 6a & 6b)
- 7 - Using silicone sealant or similar, seal the opening around the wire to maintain water tight state. (Fig 7)
- 8 - Install speakers and baffle assembly as per speaker manufacturer directions.



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6a



Figure 6b



Figure 7