

REDROCK^{4X4}

1997-2006 Wrangler Side Steps

Contents:

- (2) - Side Steps
- (4) - Spacers

Tools Needed:

Basic Hand Tools



It is recommended that you have an additional person available to help during this installation, parts can be awkward to hold and support by yourself.



1 Locate the factory body mount bolts. Using a 5/8" socket, remove the front and rear bolt.



2 Place the provided spacer below the factory rubber bushing.



3 Install the side step to the body mounts using the factory bolts.



4 Repeat steps 1-3 on the other side.